# DXR-701



Installation Instructions



# Linear

(760) 438-7000 • FAX (760) 438-7043 USA & Canada (800) 421-1587 & (800) 392-0123 Toll Free FAX (800) 468-1340 www.linearcorp.com

#### PRODUCT DESCRIPTION

The DXR-701 is a digital receiver with an isolated relay output designed for use with Linear's DX Format transmitters. This receiver can be used in a variety of remote control applications. When the receiver detects a signal from a transmitter programmed into its memory, the relay output activates. The relay has four optional output configurations.

In a typical installation, the receiver is connected to an alarm control panel, door strike, camera, high current relay or some other device. A transmitter is used to activate or control the device. The receiver should be mounted with the supplied mounting bracket indoors or inside a weather resistant non-metallic housing.


The digital DX code format features over a million possible codes. The DX transmitters are precoded at the factory to unique codes, so no field coding is required. Receivers must be programmed to the transmitter's code before system testing and operation. Up to 32 transmitters can be programmed into the receiver's memory. The memory is retained, even without power, The unit can be powered from a 11-17 VDC or 12-16 VAC power source. The relay's normally open and normally closed contacts can switch up to 1 amp at 24 volts AC/DC.

Cutting jumpers select how the relay activates. The factory setting causes the relay to engage for four seconds each activation. Optionally, the relay can be set to engage for one second, toggle on with one activation then off with the next, or latch engaged until reset by pressing the program button,


A nine-inch wire lead serves as the receiver's antenna. The red program indicator lights during RF reception. The installer can verify that signals are being sent from transmitters and diagnose interference problems by viewing the indicator. The indicator also lights during memory programming/erasing and flashes to count the number of transmitters in memory. The program button and indicator function as follows:

FUNCTION	PROGRAM BUTTON	PROGRAM INDICATOR	
NORMAL OPERATION	RELEASES LATCHED RELAY	LIGHTS AS TRANSMITTERS ARE RECEIVED, BLINKS AS INTERFERENCE IS RECEIVED	
PROGRAMMING MEMORY	PRESS AND RELEASE	LIGHTS FOR 3 SECONDS FOR PROGRAMMING	
CHECKING MEMORY	PRESS UNTIL BLINK AND RELEASE	BLINKS THE NUMBER OF TRANSMITTERS IN MEMORY	
ERASING MEMORY	PRESS AND HOLD THROUGH THE COUNT AND HOLD FOR 4 SECONDS MORE	AFTER BLINKING COUNT. A PAUSE THEN A SINGLE BLINK AS MEMORY IS ERASED	

### **DXR-701 FEATURES**



#### **RELAY OPTION JUMPERS**



RELAY OPTION	JUMPER WJ1	JUMPER WJ2		
4 SECOND LATCH	SOLID	SOLID		
1 SECOND LATCH	CUT	SOLID		
LATCH UNTIL RESET ++	SOLID	CUT		
TOGGLE ON AND OFF ++	CUT	CUT		
BE SURE POWER IS OFF WHEN CUTTING JUMPERS				

## **MOUNTING RECEIVER**




SNAP RECEIVER ONTO BRACKET


MOUNTING NOTES: 1 MOUNT RECEIVER AS HIGH AS POSSIBLE FOR BEST RADIO RANGE


2 KEEP RECEIVER AWAY FROM METAL OBJECTS THAT CAN DECREASE RADIO RANGE BY SHIELDING THE SIGNAL

3, KEEP RECEIVER AWAY FROM MOTORS, FANS AND OTHER ELECTRICAL DEVICES THAT MAY CAUSE INTERFERENCE AND REDUCE RADIO RANGE




#### **TERMINAL CONNECTIONS**






DOOR STRIKE CONNECTION



SECURITY CAMERA CONNECTION LATCHING RELAY OPTION



EXTERNAL RELAY CONNECTION TOGGLE RELAY OPTION

# ++ CAN BE RESET BY PUSHING THE PROGRAM BUTTON ONCE PROGRAMMING MEMORY

1. PRESS AND RELEASE PROGRAM BUTTON

2. PROGRAM INDICATOR WILL LIGHT IF THERE IS ROOM IN MEMORY FOR ANOTHER TRANSMITTER. (32 TRANSMITTERS MAX.)

3 SEND SIGNAL FROM TRANSMITTER, INDICATOR WILL FLICKER AS SIGNAL IS

4. REPEAT THE ABOVE THREE STEPS FOR EACH ADDITIONAL TRANSMITTER.

NOTE: THE RECEIVER CAN MEMORIZE EACH TRANSMITTER MORE THAN ONCE, TO PREVENT DUPLICATE ENTRIES, PROGRAM EACH TRANSMITTER INTO RECEIVER ONLY ONCE,





## **CHECKING MEMORY**

1. PRESS PROGRAM BUTTON AND HOLD FOR ABOUT TWO SECONDS UNTIL INDICATOR LIGHTS THEN RELEASE

COLINT THE NUMBER OF INDICATOR BLINKS, THIS IS THE TOTAL NUMBER OF TRANSMITTERS PROGRAMMED. PUSH UNTIL INDICATOR LIGHTS

> NOTE: DO NOT CONTINUE TO PRESS BUTTON OR MEMORY WILL BE ERASED


#### SYSTEM TESTING

1. ACTIVATE EACH TRANSMITTER, ONE AT AT TIME.

2. LISTEN FOR RELAY CLICK IN

3. VERIFY THAT THE DEVICE CONNECTED TO THE RECEIVER RESPONDS.

VARIOUS LOCATIONS TO DETERMINE SYSTEM PERFORMANCE




### **ERASING MEMORY**

1. PRESS PROGRAM BUTTON AND CONTINUE TO HOLD IT THROUGH THE COUNT OF THE TRANSMITTERS

2. CONTINUE TO HOLD THE BUTTON AFTER THE COUNT UNTIL THE INDICATOR BLINKS ONE MORE TIME (ABOUT FIVE SECONDS AFTER THE COUNT).

3 ALL TRANSMITTERS PROGRAMMED INTO MEMORY WILL BE EBASED.



PUSH AND HOLD BUTTON FOR FIVE SECONDS AFTER THE TRANSMITTER COUNT

#### LINEAR LIMITED WARRANTY

This Linear product is warranted against defects in material and workmanship for twelve (12) months. The Warranty Expiration Date is labeled on the product. This warranty extends only minimum. The vicanismy expiration bate is subject on the product. This warrang extends only to wholesale customers who buy direct from Linear or through Linear's normal distribution channels, Linear does not warrant this product to consumers. Consumers should inquire from their selling dealer as to the nature of the dealer's warranty, if any. There are no obligations or liabilities on the part of Linear Corporation for consequential damages arising out of or in connection with use or performance of this product or other indirect damages with respect connection with use or performance of this product or other influence utilities will respect to loss of property, revenue, or profit, or cost of removal, installation, or reinstallation. All implied warranties, including implied warranties for merchantability and implied warranties for filmss, are vaid only until Warranty Expiration Date as tabeled on the product. This Linear Corporation Warranty is in lite of all other warranties express or implied.

All products returned for warranty service require a Return Product Authorization Number (RPA#).

Contact Linear Technical Service at 1-800-421-1587 for an RPA# and other important details. IMPORTANT !!!

Linear radio controls provide a reliable communications link and fill an important need in portable wireless signalling. However, there are some limitations which must be observed.

For U.S. installations only: The radios are required to comply with FCC Rules and Regulations

- as Part 15 devices, As such, they have limited transmitter power and therefore limited range, A receiver cannol respond to more than one transmitted signal at a time and may be blocked
- by radio signals that occur on or near their operating frequencies, regardless of code settings Changes or modifications to the device may void FCC compliance. Intrequently used radio links should be tested regularly to protect against undelected
- A general knowledge of radio and its vagaries should be gained prior to acting as a wholesale ributor or dealer, and these facts should be communicated to the ultimate users

Copyright © 2002 Linear Corporation

220463 A