


Set Up



1. Position the Scarecrow so the area you wish to protect is within its 105 degree detection area. Avoid pointing it at any objects where movement may cause "false triggering" ie: sidewalks, roads or waterfalls.
2. Adjust the sensitivity dial to the lowest setting that will still pick up your target animal, (see chart on page 6 in the instruction manual).

Sensing Area



3. Fine tune the sprinkler to ensure the water covers the area you wish to protect.