free@**home**

Welcome
to your new Thermostat

Finally... a wireless thermostat that is easy to operate at home, at the office, from anywhere.

Tap to activate your heater.

Activate the fan whenever you like.

Utilize the energy-saving mode while you are away.

Tap to activate your air-conditioning.

Auto

70

72

AUX

ABB

Function Overview

Tap on a symbol to activate a function.

It is 72° and the thermostat is heating.

It is 72° and cooling. The fan is manually on. It is in energy-saving ECO mode.

It is 72°. Press and hold the big number for 3 seconds. You can now clean the screen.

SYMBOL	DESCRIPTION
70 72	**TEMP VALUES -** The large number shows the current temp and the small number the setpoint temp. Another option is to display the outside temp.
⌃	**ARROWS -** Tap up or down to change the setpoint temp.
⚙	**SETTINGS -** Tap for settings mode, tap again to exit.
🌀	**FAN -** The fan can be set to ON or AUTO mode. By default, it is in AUTO mode. Tap to turn on the fan.
♨	**HEATING -** Tap to enable and disable the heating mode.
⌒	**HEATING INDICATOR -** When red the device is heating.
❄	**COOLING -** Tap to enable and disable the cooling mode.
⌣	**COOLING INDICATOR -** When blue the device is cooling.
🍃	**ECO -** When operator is away, the device can be set to save energy. The setpoint is decreased for heating or increased for cooling. Tap to activate and deactivate.
⏻	**ON/OFF -** Tap to turn the Thermostat OFF/ON, and to turn OFF/ON all appliances that are connected to it. Only the protection function remains active.
+	**ACCESSORY-** Activate/deactivate another function (humidifier or dehumidifier).
AUX	**AUXILIARY HEATING -** This is used only if a heat pump is controlled. If symbol is on, auxiliary heating is enabled.
✚	**PROTECTION -** Indicates heating/cooling was turned on automatically to protect the HVAC from overload and the home from extreme hot or cold temperatures.

For a complete system manual, please go to
www.abb.com/freeathome