

CBA[®]

Dummy Camera Series

Manual



Note: Dummy cameras are to be used as a deterrent only.

SECO-LARM[®] SLI

FC CE RoHS

Note: Model numbers that end with "Q" or that have a round green "Q" sticker signify RoHS-compliant products.

Introduction

CBA Series Dummy Cameras are a great low-cost way to deter crime at home, at the office, in parking lots, around parks and playgrounds, and much more. Dummy cameras create the perception of electronic surveillance, without the cost and maintenance of CCTV equipment.

The CBA product line contains a wide variety of products to fit a wide variety of applications. No matter the installation, there is a CBA Series Dummy Camera to fit its needs!

Before Starting

1. Please read this manual carefully and keep it for future reference.
 2. If the dummy camera has LEDs, do not aim the LEDs directly at the eyes.
 3. Do not disassemble the dummy camera. There are no user-serviceable parts inside.
-

Installation:

1. Choose a suitable location for mounting. The higher up a dummy camera is installed, the more authentic it will appear.
2. If the dummy camera has wires, make sure the wires are inserted through the bracket and secured so they will not fall out over time.
3. For models with LEDs, connect to power or install batteries as indicated on the product (power supplies and batteries not included).

Note: Be sure to note the type of batteries required. If rechargeable batteries are required, make sure to use rechargeable batteries

Note: Real CCTV cameras do not usually have flashing LEDs. If the dummy camera has a flashing LED, do not install the batteries to make the dummy camera appear more realistic.

4. Be sure to mount the dummy camera securely using any included hardware.
 5. Aim the unit at the desired location.
-

Also Available from the CBA Series:

Dummy Photobeam Detector



BD-T100Q

(Uses 2x AA batteries)

Dummy Keypad



KD-100Q

(Uses 4x AAA batteries)

The CBA Series Dummy Camera Line:

Dummy Mini Dome Camera



VD-20NN

Dummy Mini Dome Camera with Flashing LED



VD-20BNB
(Uses 2x AA batteries)

Dummy Mini PTZ Camera with Flashing LED



VD-40BNA
(Uses 2x AA batteries)

Dummy Rollerball Camera with Flashing LED



VD-20BN
(Uses 2x AA batteries)

Dummy Rollerball Camera with Working IR LEDs



VD-20BNNAQ
(Uses 2x AA batteries)

Dummy Box Camera with Flashing LED



VD-10BNA
(Uses 2x AAA batteries)

Dummy IR Bullet Camera with Flashing LED



VD-30BS
(Uses 2x AA batteries)

Dummy IR Bullet Camera with Working IR LEDs



VD-10PL
(Uses 12VDC power)

Dummy Security Camera with Flashing LED



VD-10BN
(Uses 2x AA batteries)

Dummy Bullet Camera with Flashing LED



VD-30BNA
(Uses 2x AA batteries)

Solar-Powered Dummy Camera with Working IR LEDs



VD-30SS
(Uses 2x rechargeable AA batteries)

Dummy Bullet Camera with Working IR LEDs



VD-30BNNAQ
(Uses 2x AAA batteries)

Troubleshooting

LED is not flashing

- Check the batteries.

Working IR LED will not turn ON

- Check the batteries.
- Check ambient lighting. If the dummy camera is exposed to light, the working IR LEDs will not turn ON.

Note: Not all dummy cameras have flashing LEDs or working IR LEDs.

IMPORTANT

Users and installers of this product are responsible for ensuring this product complies with all national, state, and local laws. SECO-LARM is not responsible for the use of this product in violation of any current laws or statutes.

SECO-LARM makes no warranties expressed or implied that dummy cameras will prevent any criminal or inappropriate activity. SECO-LARM disclaims any and all liability for any damages to property or persons as a consequence of the purchase or installation of dummy cameras. Neither SECO-LARM nor any of its officers, employees, or resellers shall be subject to any liability arising out of or in connection with this sale. The purchaser assumes all risk and all liability arising out of the installation of dummy cameras.

WARRANTY: This SECO-LARM product is warranted against defects in material and workmanship while used in normal service for the life of the product from the date of sale to the original customer. SECO-LARM's obligation is limited to the repair or replacement of any defective part if the unit is returned, transportation prepaid, to SECO-LARM. This Warranty is void if damage is caused by or attributed to acts of God, physical or electrical misuse or abuse, neglect, repair or alteration, improper or abnormal usage, or faulty installation, or if for any other reason SECO-LARM determines that such equipment is not operating properly as a result of causes other than defects in material and workmanship. The sole obligation of SECO-LARM and the purchaser's exclusive remedy, shall be limited to the replacement or repair only, at SECO-LARM's option. In no event shall SECO-LARM be liable for any special, collateral, incidental, or consequential personal or property damage of any kind to the purchaser or anyone else.

NOTICE: The information and specifications printed in this manual are current at the time of publication. However, the SECO-LARM policy is one of continual development and improvement. For this reason, SECO-LARM reserves the right to change specifications without notice. SECO-LARM is also not responsible for misprints or typographical errors.

Copyright © 2013 SECO-LARM U.S.A., Inc. All rights reserved. This material may not be reproduced or copied, in whole or in part, without the written permission of SECO-LARM.


SECO-LARM® U.S.A., Inc.

16842 Millikan Avenue, Irvine, CA, 92606

Phone: (949) 261-2999 | (800) 662-0800

Website: www.seco-larm.com

Email: sales@seco-larm.com

 PICSN1
PICRN1

MICBA_1312.docx