



# Quick Guide

## Internet Hub

Model: HU-100



iPhone not included

### 1. Package Contents



Internet Hub



Ethernet Cable




Power Adapter


NOTE: 4 x AAA-Batteries required in the Internet Hub for backup power.

### 2. Install the Internet Hub


1. Connect your Hub to an available Port on your Internet Router using the Ethernet cable.




2. Plug in the Power Adapter.



3. Insert 4 x AAA-Batteries in the Hub for backup power in case of power outage. (Optional)



### 3. Download the SkylinkNet App



1. Tap on App Store



4. When download is completed, it will show on your Home Screen.



2. Tap on Search Icon and search for "SkylinkNet"



3. Tap on Free Button to download the App.

NOTE: Only the "SkylinkNet" App will work with the Internet Hub.




### 4. Create a SkylinkNet Account




1. Open the SkylinkNet App and tap on "Create Account".



2. Enter your information and tap on "Sign Up".



3. Check your email to activate your account and tap on "Continue" to log in.



4. Click on the link from the email to activate your account.




5. Now you are ready to login to your account

### 5. Set up the Internet Hub



1. Tap on "Set up Hub".



2. Tap on "Initialize a new Hub".




3. Follow the instruction on screen to connect the Internet Hub.



4. Enter your information and tap on "Continue".



5. Follow the instruction on screen to reset the Internet Hub and tap "Continue".



6. Hub is added and you will see a green or red dot indicating if it's connected to the Hub.


### 6. Setup Hub Keypad Password




1. Go to "More".



2. Tap on "System Settings".



3. Tap on "Hub Keypad Password".



4. Enter Passcode and tap on "Save".


### 7. Setup Time Zone




1. Go to "More".



2. Tap on "System Settings".




3. Tap on "Time Settings".




4. Set your time zone and tap on "Save".


### 8. Add Sensors and Keychain Remote (Sold Separately)



1. Go to "More" and tap on "System settings".




2. Tap on "Setup Wizard".



3. Tap on "Add Device".



4. Tap on "Sensors" or "Security Remote".




5. Select the type of sensor you want to add.




6. Name your sensor and location and tap "Continue".



7. Tap the "Learn Now" button and follow the video to activate the sensor.



8. Now trigger the sensors to test if the SkylinkNet App is showing the sensor status correctly.



NOTE: If motion is detected, a red led light inside the sensor will flash. Sensor will not be triggered by new motion unless no motion has been detected for 15 seconds.

## 9. Add HomeControl Receiver (Sold Separately)

- Go to "More" and tap on "System settings".
- Tap on "Setup Wizard".
- Tap on "Add Device".
- Tap on "Lighting" or "Appliances".

**Learning Mode**

- To add the device now, put the device into Learn Mode, then press "Learn Now". If you are not certain how to put the device into Learn Mode, refer to the manual of the device.
- Tap the "Learn Now" button.

**5. Name your "Lighting" or "Appliances"; then, location and tap "Continue".**

## 10. Home Screen Overview

- Online/Offline:** Shows the hub name and connection.
- Sensors:** Sensors icons are blue/red. The blue sensor icons will turn red if its activated.
- Receivers:** Push icons are black.
- Settings:** Settings for individual sensor, remote or receiver.
- Menu Bar:** Choose between different screens.
- Push Notification:** Receive push notification anytime a new activity takes place.

## 11. Sensor Settings

Tap on the gear icon to edit the settings of this specific sensor.

- Alarm Settings:** Select when this sensor should activate an alarm.
- Push Notification:** Select if you want to receive a push notification during an alarm only or always when a sensor is activated.
- Chime:** If enabled, the Internet hub will sound an alert chime when this sensor is activated.
- Learn:** Learn the sensor with the Internet hub. (Learn the sensor if you have selected "Learn Later" in Step 8 of "Add Sensors and Keychain Remote".)
- Rename:** Change the name of this sensor.
- Delete:** Delete this sensor from the hub.

## 12. Alarm Screen Overview

- Status of the Alarm System:** Shows the current status (e.g., SYSTEM DISARMED).
- Arm Home, Arm Away / Exit Delay:** Buttons to arm the system in different modes.
- Slide to activate the hub siren in emergency:** A slider control for the panic siren.

## 13. Arm Home / Arm Away

**Arm Home**

Select "Arm Home" to protect while you're at home. This mode deactivates motion sensors but leaves other sensors activated.

**Arm Away / Exit Delay**

Select "Arm Away" to protect your home when you're away. This mode activates or triggers the alarm after a default set of time, giving you enough time to get in and out of your house to arm/disarm the alarm system.

## 14. Disarm Alarm System

When an alarm is activated, a push notification will be sent to all users and your smartphone will play an alarm sound.

Tap the "Disarm" Button to disarm the alarm system.

## 15. Keychain Remote

- Arm Away**
- Arm Home**
- Disarm**
- Panic Button:** Press and hold the Panic Button for 5 sec. to activate it.

## 16. Event Log

See all the recent activities of the Alarm System on the Event Log.

- Go to "More".
- Tap on "System Settings".
- Tap on "Event Log".

## One Year Warranty / Customer Service

This product is guaranteed to be free of defects in materials and workmanship for 1 year from the date of purchase. If this product is defective, call 1-800-304-1187 for repair or replacement parts. Guarantee does not include normal wear and tear or batteries.



If you have any questions, problems or missing parts, please call Skylink Customer Support:

1-800-304-1187

9:00am – 5:00pm EST, Monday-Friday

Or e-mail us at support@skylinkhome.com

www.skylinkhome.com